

## Parrot Minikit Slim / Chic

User guide

# Content


Content 2		
Getting started	3	
Before your begin	3	
Charging the Parrot MINIKIT Slim / Chic	. 3	
Installing the Parrot MINIKIT Slim / Chic	. 3	
Accessing the Parrot MINIKIT Slim / Chic menu	. 4	
Establishing a Bluetooth connection with a phone	4	
Pairing and connecting a phone / PDA by Bluetooth	. 4	
Automatic connection	. 5	
Managing the "Memory full" problem	. 5	
Synchronizing the phonebook	. 5	
Automatic synchronisation	. 5	
Sending contacts via Object Push	. 5	
Resetting the Parrot MINIKIT Slim / Chic	. 6	
Phone	. 7	
Making and receiving calls	7	
Calling a contact in the phonebook	. 7	
Bringing up the last dialled number	. 7	
Receiving a call	. 7	
Answering a call	. 7	
Declining a call	. 7	
Using the Parrot MINIKIT Slim / Chic while on a call	. 8	
Adjusting the volume	. 8	
Transfering a call to the phone	. 8	
Managing a second call	. 8	
Managing voice mail	. 8	
Ending a call	. 8	
Using voice recognition	. 9	
Recording voice tags	. 9	
Making a call via voice recognition	. 9	
Calling a contact with several phone numbers	. 9	
Exiting voice recognition mode	10	

# Getting started

#### Before your begin

Charging the Parrot MINIKIT Slim / Chic • The Parrot MINIKIT Slim / Chic must be charged before being used for the first time. To do so, plug the charger into your vehicle's cigar lighter or connect the Parrot MINIKIT Slim / Chic to your computer using the USB/mini USB cable (provided).

**Note :** The cigar lighter charger of the Parrot MINIKIT Slim / Chic can only be used in cars.



- The LED located next to the mini-USB port turns red to indicate that the battery is being charged. The LED turns off once the battery is fully charged.
- When the battery level is low, the Parrot MINIKIT Slim / Chic emits a series of beeps.

Installing the Parrot MINIKIT Slim / Chic

• Use the clip located on the back of the Parrot MINIKIT Slim / Chic to fix it to the sun visor of your vehicle.



• You can also use your Parrot MINIKIT Slim / Chic at home by simply placing it on a stable surface.

Press the red button for 2 seconds to turn on the Parrot MINIKIT Slim / Chic.


Accessing the Parrot MINIKIT Slim / Chic menu

- Press the jog wheel to access the main menu.
   > The Parrot MINIKIT Slim / Chic says the name of the current menu.
- Browse through the menus by turning the jog wheel and confirm with the green button or by pressing the jog wheel.
- To exit the menu, press the red button or wait for a few seconds.

### Establishing a Bluetooth connection with a phone

Pairing and connecting a phone / PDA by Bluetooth Before using the Parrot MINIKIT Slim / Chic with your phone, you first have to pair both devices. The pairing process is only required once. Depending on the model of your phone, the connection will then be automatic as soon as you enter your vehicle.

- From your *Bluetooth* phone, search for *Bluetooth* peripherals (refer to your phone user guide for more information).
   > The list of the available *Bluetooth* peripherals is displayed.
- 2. Select «Parrot MINIKIT Slim / Chic».
- Enter the «1234» PIN code and validate.
   > The Parrot MINIKIT Slim / Chic says «Pairing successful» when both devices are paired.



Automatic connection	Once your phone is paired to the Parrot MINIKIT Slim / Chic, the connection between both devices will be automatically established each time you enter your vehicle if your screen is plugged in.
Managing the	You can pair up to five devices.
"Memory full" problem	If you attempt to pair a sixth phone, the kit says «memory full». You must clear the memory by holding down both the red and green buttons for three seconds. Doing so also clears all the contacts and the associated voice tags.

#### Synchronizing the phonebook

**Note :** Only contacts stored in the memory of the phone will be synchronised in the kit's memory.

Automatic With most of the *Bluetooth* phones, the phonebook is automatically synchronized in the kit's memory. Refer to the <u>compatibility section</u> of our website for more information.

**WARNING :** The automatic synchronization is limited to 2 000 contacts for each paired phone.

Sending contacts via Object Push

If your phone doesn't support automatic synchronization, you can also send contacts manually from your mobile to the car kit. To do so:

- 1. Press the jog wheel and select **Receive contacts**.
- 2. Refer to your phones 'user guide for more information about sending contacts (via Object Push).

#### Resetting the Parrot MINIKIT Slim / Chic

In case of malfunction, you can reboot the Parrot MINIKIT Slim / Chic. To do so:

- 1. Press simultaneously the jog wheel and the Reset button located at the back of the Parrot MINIKIT Slim / Chic.
- Release the Reset button.
   You can now release the jog wheel.

Before using your Parrot MINIKIT Slim / Chic telephony function, you first have to pair and connect both devices.

► Refer to the <u>Pairing and connecting a phone via Bluetooth</u> section for more information.

#### Making and receiving calls

#### Making a call

Calling a contact in the phonebook	<ul> <li>If the contact you want to call is in the phonebook of the phone connected to the Parrot MINIKIT Slim / Chic:</li> <li>1. Press the jog wheel to enter the main menu and select Phonebook.</li> </ul>
	<ul> <li>2. Select a letter and press the jog wheel.</li> <li>&gt; Once the contact chosen: <ul> <li>Press the green button to call this contact.</li> <li>Or use the jog wheel to choose between different numbers of the same contact.</li> </ul> </li> </ul>
Bringing up the last dialled number	Hold down the green key of the Parrot MINIKIT Slim / Chic for two seconds to redial the last dialled number.

#### Receiving a call

**Note :** The name of the caller is announced if his number is recorded in the phonebook of the phone connected to the Parrot MINIKIT Slim / Chic.

- Answering a call Press the green button to answer an incoming call.
- Declining a call Press the red button to decline an incoming call.

#### Using the Parrot MINIKIT Slim / Chic while on a call

Adjusting the volume	Use the jog wheel during a call to adjust the communication volume. > The volume setting is saved for subsequent calls.
Transfering a call to the phone	<ul> <li>During a call, if you want to continue the conversation on your phone (private conversation), press the green button of the Parrot MINIKIT Slim / Chic.</li> <li>The call is automatically transferred to the phone.</li> </ul>
	<ul> <li>If you want to switch back to the kit, press the green button again.</li> </ul>
Managing a second call	<ul> <li>During a call, you can receive another call if your phone supports this functionality.</li> <li>Press the green button to accept the second incoming call.</li> <li>&gt; The first call is automatically put on hold.</li> </ul>
	<ul> <li>Press the red button to decline the second incoming call. You can also hang up directly from your phone.</li> <li>Press the green button to switch from a call to another.</li> </ul>
Managing voice mail	During a call, the Parrot MINIKIT Slim / Chic allows you to send DTMFs to manage your voice mail for example. To do so :
	<ol> <li>Press the jog wheel to access the DTMF menu.</li> <li>&lt; 0 » is displayed by the kit.</li> </ol>
	2. Use the jog wheel to select your DTMF between the following possibilities : 0,1,2,3,4,5,6,7,8,9,# or *.
	3. Press the jog wheel to send this DTMF to your phone.
Ending a call	Press the red button to end a call.

### Using voice recognition

Before using your Parrot MINIKIT Slim / Chic voice recognition function, you first have to pair and connect both devices.

- ▶ Refer to the **Pairing and connecting a phone via Bluetooth** section for more information.
- Recording voice tags All your contacts, after automatic synchronization or Object Push process, are directly provided with a voice tag in the Parrot MINIKIT Slim / Chic. Consequently, you don't have to record your own voice tag on each contact to make a call via the voice recognition process. However, if the Parrot MINIKIT Slim / Chic doesn't understand the name of one of your contacts or if a voice tag is too long, you can record a new one. To do so, press the jog wheel and select Add voice tags. Making a call via voice recognition 1. Press the green key to launch the voice recognition feature. > A beep is emitted. 2. Say the « Call » keyword and the name of the contact you want to call. > The call is automatically launched if the voice tag is correctly understood. If it is not the case, a confirmation message is asked by the kit. 3. Confirm by saying « yes » or « call ». > The call is initiated. Calling a contact with • If there are several phone numbers associated to the contact several phone numbers you want to call, you can specify the type of number. • To do so, the following vocal commands are available: - Home - Work - Mobile - Other - At home - At work - Cellular - General - Office - Cell - Default - On mobile - At office - Preferred - At the office - On cellular - On cell - On mobile phone - On cellular phone
  - On cell phoneMobile phone
  - Cellular phone

  - Cell phone

Exiting voice recognition Press the red button to exit voice recognition mode. mode